

Leybold Singapore
(A division of Vacuum Technique Singapore Pte. Ltd)
42 Loyang Drive Loyang Industrial Estate Singapore 508962

Dear Valued Leybold Customer,

Good day to you.

Please be informed that the part number **LEYBONOL 100** has been officially replaced with **LEYBONOL 130** as part of our ongoing product enhancement and standardization efforts.

Test & Pump Performance

Internal testing has confirmed that with LVO 130, pump performance remains at the same premium level as with LVO 100.

- No change in oil carry-over (OCO), ultimate pressure and pumping speed.
- Oil change intervals remain the same

Compatibility

LVO 130 is fully compatible with LVO 100 across all pump ranges.

- No special procedures (e.g., flushing) are required when switching.
- For best pump performance, mixing oils should be avoided.

Easy changeover is applied in 3 steps:

1. Drain the oil from warmed up pump
2. Fill in the new oil until minimum oil level and start the pump again for a short running (10min) then drain the oil
3. Fill in new oil until optimal oil level and change the oil sticker to new Oil type

Thank you,
Yours Sincerely,

Santos A. Vicente (JR)
Business Line Manager
Mobile: +60125002879
E-mail: jr.vicente@atlascopeco.com
Vacuum Technique Service Division - SEA & Oceania